

Willard Says.....

WINCH INSTALLATION


affects performance of the winch, hence, performance of the dredge system. Improper installation will prevent a winch from serving its intended purpose. After a winch with the desired mechanical features is selected to develop a certain linepull, inhaul cable at the desired speed and spool the necessary amount of cable, it must be properly installed so that it can develop its full capability. Proper installation assures that the winch will operate with a minimum of problems.

ALIGNMENT

The winch must be mounted so that the drum shaft is at a 90-degree angle relative to a line that extends from the center of the drum to the winch sheave. Failure to align the winch will prevent the cable from winding onto the drum as it should. See more below under "fleet angle."

It is a rare application where a cable extends directly from the winch drum to the actual load. Successful operation of such an arrangement requires that the load always stay aligned relative to the winch drum.

The common arrangement is for the winch cable to leave the drum and go through a fixed sheave block, which we will call the "winch sheave." Coming out of the winch sheave, the cable goes on to another sheave or to an anchor or other load. Causing the cable to go through the winch sheave before it goes elsewhere makes it possible to achieve and maintain winch drum alignment. The sketch below shows the proper arrangement.




Misalignment is indicated when cable tends to pile up on one end of the drum. Recheck the alignment.

FLEET ANGLE

is the angle between the tensioned cable as it extends from either end of the winch drum to the winch sheave relative to a line that extends from the center of the drum to the winch sheave. If the fleet angle exceeds about 2 degrees it is likely that the cable will not spool onto the drum in uniform layers—the cable will “pile up” on the drum. Improper cable spooling leads to “nesting.” The cable should wind onto the drum and fill it from end to end building layer on top of layer.

Nesting is the name for what happens when heavily tensioned cable knifes down through loosely wound or “piled up” underlying layers and wedges into place. Consequently the nested cable will not pay off the drum and must be freed by the frustrated operator.



The fleet angle depends on two factors as shown on the above sketch—the length of the winch drum (W) and the distance between the drum and the winch sheave (D). The chart below can be used as a guide to determine the minimum distance (D) that corresponds to various length of winch drums (W). Distance (D) is a minimum. There is no limit to the maximum distance (D).

W INCHES	10	12	14	16	18	20	22	24
D FEET	13	15	18	20	23	25	28	30

W Drum Length, **D** Distance, drum-to-winch sheave

SHIMMING

Winches—especially planetary winches—are relatively fragile collections of steel parts until they are firmly bolted into place. If the parts are forced out of alignment, oil leaks, slipping brakes, erratic operation or perhaps serious damage to internal parts is likely to result. Bolting a winch down on a mounting surface that is not absolutely flat will distort the winch and cause misalignment problems.

Assume that the winch has been checked for alignment and is ready to be bolted to its rigid mounting base. The mounting bolts are fitted into the holes. In a perfect world the mounting pads on the base will be milled perfectly flat so that the winch is setting foursquare on the base with each corner mounting foot in solids contact with the base. If that is the case—bolt the winch down.

Usually the winch can be teetered on its base, which indicates that it is not flat because only three of the four mounting feet are in contact with the base. This is a normal situation and the solution is to install shims into the gap between the “high” foot and the base.

Tighten the three mounting bolts that are resting firmly on the base and measure the gap thickness between the high foot and the base. Loosen the three mounting bolts, place a shim of proper thickness under the high foot to fill the gap and tighten and torque all the bolts. The winch should now be setting foursquare on its base, free of stresses that would tend to twist and force the winch assembly components out of alignment.

BRAKE CHATTER

It is not uncommon for a planetary winch—especially a ladder hoist winch—to chatter when lowering the ladder. Chatter describes what happens when the winch brake grabs and releases in rapid repetition under heavy load. Winches are not supposed to chatter. Chatter stresses all of the rigging components and the ladder structure. Carefully read the winch manufacturer’s installation literature, especially as it relates to the size of the hydraulic supply and case circulation lines. In some cases the routing of the case circulation line may be critical.

Let us know if your winch still chatters even after applying all of the solutions suggested by the winch manufacturer.

All of the chattering winches of our acquaintance are now running smooth as silk.


We can help you put the smooth on your winch too.

Winch Drum Capacity

The formula, sketch and chart below will help you determine how much cable of various sizes will spool onto a given winch.

The formula: Drum Capacity in feet = (A + B) x B x C x Factor K.

Cable Diameter, in.	1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	1
Factor K	3.29	2.21	1.58	1.19	0.93	0.74	0.61	0.43	0.24




Example to determine how much 5/8" cable will spool onto a drum with the following dimensions:

K = 0.61, A = 10.0", B = 4.5" & C = 14.0"


Drum capacity = (A + B) x B x C x 0.61 = 14.5 x 4.5 x 14.0 x 0.61 = 557 feet.

Safety considerations dictate that the drum should not be filled above the top of the flanges so reducing B to 4.0 will show that the safe rated capacity of this winch to be about 475 feet of 5/8" cable.


Willard Says.....Winch Installation




UNDERWIND
Left to Right
USE LEFT LAY ROPE



UNDERWIND
Right to Left
USE RIGHT LAY ROPE



OVERWIND
Right to Left
USE LEFT LAY ROPE



OVERWIND
Left to Right
USE RIGHT LAY ROPE

If a winch is aligned and cable still keeps piling up on one part of the drum the problem could be that the wrong cable is being used. *Willard Says.....***Wire Rope** tells how to identify different styles of wire rope. The above sketches show various winch arrangements with the recommended style of wire rope for each.

Comment, question, criticism,
information on products mentioned?
Contact willard@willardsays.com